









## **INSTALLATION INSTRUCTIONS:**

A- SELECT RECESSED MOUNTING LOCATION AND BLOCK OUT AND/OR PROVIDE ADEQUATE WALL BACKING OR FRAMING BY OTHERS.

NOTE: PLASTER FLANGES ARE 7/8" FROM FINISHED WALL.

B- USING MOUNTING PLASTER FLANGES (1), POSITION SOAP DISH (2) AND SECURE WITH CAULKING.

