

INSTALLATION INSTRUCTIONS:

A—PRIOR TO INSTALLING, VERIFY HARDWARE IS INCLUDED: CARRIAGE BOLTS ① TAPERED NUTS ② , FRONT SET SCREW ③ , AND TOILET SEAT ④ .

B—PARTIALLY INSTALL FRONT SET SCREW ③ INTO THE MOUNTING TAB ⑤ LOCATED AT THE FRONT OF TOILET SEAT ④ . SET SCREWS SHOULD NOT PASS BEYOND MOUNTING TAB.


C—POSITION THE TOILET SEAT ④ ONTO TOILET, AND FIRMLY PRESS DOWNWARD.

D—FASTEN THE TOILET SEAT ④ TO THE TOILET BY USING THE CARRIAGE BOLTS ① ON TOP OF THE TOILET SEAT ④ AND TIGHTEN BY INSTALLING THE TAPERED NUTS ② FROM THE UNDERSIDE OF THE TOILET RIM.

E—WITH TOILET SEAT ④ FASTENED, PRESS DOWNWARD ON TOILET SEAT ④ AND TIGHTEN THE FRONT SET SCREW ③ UNTIL IT FIRMLY ENGAGES UNDER THE FLUSHING RIM ⑥ .

NOTE:

1—IF TOILET SEAT HAS HOLE PLUGS, REMOVE THEM BEFORE INSTALLING TOILET.

 WHITEHALL MANUFACTURING P.O. BOX 3527 Industry, CA 91744 15125 Proctor Ave Industry, CA 91746 (626) 968-6681 FAX (626) 855-4862	TITLE LIGATURE RESISTANT TOILET SEAT *WH-LRSC		
	MANUFACTURE DATE JANUARY 2017 TO PRESENT	DATE ISSUED 05/31/16	DRAWING NUMBER 9918-206-001
		DATE REVISED <small>AND</small> A 01/23/17	